



# VTech Write and Learn Creative Center Back Panel Replacement

The back panel is an essential prerequisite when replacing various components. The back panel's purpose is to protect digital components.

Written By: Victoria Hathaway



## INTRODUCTION

The back panel is a necessary piece for the VTech Write and Learn Creative Center because the back panel protects digital components.


---



### TOOLS:

- [Phillips #2 Screwdriver](#) (1)
-

## Step 1 — Back Panel



- Remove all eleven 9mm PH 2 Phillips screws securing the back of the case.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-08-09 12:40:33 PM.